


IFB-M2005A+ USER GUIDE



RECOMMENDED JUMPER SETTING

JP1 : SONY D50 G70 G90


JP2 : SONY PC-1270/1 SWITCHER

JP3 : SONY VPH-12XX

AUTO-SWITCHING FUNCTION

SW: SET INPUT PRIORITY

DVI FIRST



COMPONENT
FIRST

